

INSTALLATION INSTRUCTIONS

- Do not store in direct sunlight for long periods of time.
- Carbide tipped saw blades recommended.
- 3/4" x 3 1/2" & 5 1/2" sizes- recommended 16" o/c spacing.
- 1" x 3 1/2" & 5 1/2" may be installed on 24" centers.
- 1/16" or 1/8" inch maximum spacing between boards recommended.
- Stainless steel screws recommended for fastening.
- Boards must be predrilled to prevent splitting.
- Carbide tipped drills required for drilling screw holes.
- 2 1/4" minimum bulge head SS screws recommended.
- Recommend counter-sinking screw heads 1/16".
- Recommend minimum (2) SS screws per board.